



EPCOM syscom

1630 Paisano Dr. – El Paso. Tx 79901.

Ph (915)533-5119

www.epcom.net

SYSCOM

Ave 20 de Noviembre No. 805

Col. Centro

Chihuahua, Chih. 31000

Tel 052 (614) 415 –

2525

www.syscom.mx

TK-3230

PARTS LIST

* New Parts. Δ indicates safety critical components.

Parts without **Parts No.** are not supplied.

Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.

Teile ohne **Parts No.** werden nicht geliefert.

L : Scandinavia

K : USA

P : Canada

Y : PX (Far East, Hawaii)

T : England

E : Europe

Y : AAFES (Europe)

X : Australia

M : Other Areas

TK-3230 (Y50-6160-XX)

TX-RX UNIT (X57-7330-10)

Ref. No.	Address	New parts	Parts No.	Description	Desti-nation	Ref. No.	Address	New parts	Parts No.	Description	Desti-nation
TK-3230						C21			CC73HCH1H470J	CHIP C 47PF J	
1	3A	*	A02-3975-13	PLASTIC CABINET ASSY (REAR)		C22			CK73HB1H471K	CHIP C 470PF K	
2	1A	*	A02-3977-03	PLASTIC CABINET ASSY (FRONT)		C23			CK73HB1C103K	CHIP C 0.010UF K	
4	3B	*	B09-0710-03	CAP		C25			CK73HB1H471K	CHIP C 470PF K	
5	1C	*	B62-1976-10	INSTRUCTION MANUAL		C27			CC73HCH1H130G	CHIP C 13PF G	
8	2A	*	E37-1390-05	PARALLEL CORD		C28			CC73HCH1H110G	CHIP C 11PF G	
10	2B	*	F07-1929-03	COVER (ANTENNA CAP)		C29			CC73HCH1H101J	CHIP C 100PF J	
12	2B	*	G10-1378-04	FIBROUS SHEET		C30			CK73GB1H103K	CHIP C 0.010UF K	
16	3D	*	H52-2168-02	ITEM CARTON CASE	K	C31,32			CC73HCH1H100D	CHIP C 10PF D	
18	1A	*	J19-5508-03	HOLDER (PTT)		C33			CC73HCH1H0R5B	CHIP C 0.5PF B	
19	2C	*	J29-0736-05	HOOK ASSY ACCESSORY		C34,35			CC73HCH1H100D	CHIP C 10PF D	
21	2B	*	K29-9397-03	KNOB (VOLUME)		C36,37			CC73HCH1H101J	CHIP C 100PF J	
22	1A	*	K29-9398-03	BUTTON KNOB (PTT)		C38			CK73HB1H471K	CHIP C 470PF K	
23	2A	*	K29-9399-02	KEY TOP		C39			CC73HCH1H101J	CHIP C 100PF J	
A	2B	*	N14-0840-05	CIRCULAR NUT		C40			CS77AAQJ220M	CHIP TNL 22UF 6.3WV	
B	2C	*	N35-3005-43	BINDING HEAD MACHINE SCREW	BK	C41			CC73HCH1H050B	CHIP C 5.0PF B	
C	2A,3A	*	N80-2006-43	PAN HEAD TAPTITE SCREW		C43			CC73HCH1H100D	CHIP C 10PF D	
25	2C	*	N99-2063-05	SCREW SET ACCESSORY	K	C44			CC73HCH1H050B	CHIP C 5.0PF B	
27	2A	*	T07-0362-25	SPEAKER		C45,46			CK73HB1H471K	CHIP C 470PF K	
28	2B	*	T90-1068-05	ANTENNA ELEMENT		C47			CK73HB1A104K	CHIP C 0.10UF K	
30	1D	*	W08-0994-05	AC ADAPTER (120V) ACCESSORY	K	C48,49			CK73HB1H471K	CHIP C 470PF K	
31	2D	*	W08-0995-05	CHARGER ACCESSORY	K	C50,51			CC73HCH1H030B	CHIP C 3.0PF B	
						C52			CC73HCH1H050B	CHIP C 5.0PF B	
						C53			CC73HCH1H080B	CHIP C 8.0PF B	
						C54			CC73HCH1H050B	CHIP C 5.0PF B	
						C55			CC73HCH1H101J	CHIP C 100PF J	
						C57,58			CC73HCH1H101J	CHIP C 100PF J	
						C60			CC73HCH1H120J	CHIP C 12PF J	
						C100			CK73HB1H471K	CHIP C 470PF K	
						C101			CC73HCH1H1R5B	CHIP C 1.5PF B	
						C103			CK73HB1A104K	CHIP C 0.10UF K	
						C111			CK73HB1A104K	CHIP C 0.10UF K	
						C112			CK73HB1H471K	CHIP C 470PF K	
						C113			CC73HCH1H150J	CHIP C 15PF J	



