



## EPCOM syscom

1630 Paisano Dr.  
El Paso. Tx 79901.  
Ph (915)533-5119

[www.epcom.net](http://www.epcom.net)

## SYSCOM

Ave 20 de Noviembre No. 805 Col. Centro  
Chihuahua, Chih. 31000  
Tel 052 (614) 415 – 2525 [www.syscom.mx](http://www.syscom.mx)

# NX-220

## PARTS LIST

\* New Parts. Δ indicates safety critical components.

Parts without **Parts No.** are not supplied.

Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.

Teile ohne **Parts No.** werden nicht geliefert.

L : Scandinavia

Y : PX (Far East, Hawaii)

C : China

K : USA

T : England

X : Australia

P : Canada

E : Europe

M : Other Areas

### NX-220 DISPLAY UNIT (X54-3760-XX)

Ref. No.	Address	New parts	Parts No.	Description	Desti-nation
<b>NX-220</b>					
1	2B	*	A02-4130-03	PLASTIC CABINET ASSY	K,E3
2	2B	*	A02-4131-03	PLASTIC CABINET ASSY (4KEY)	K2,E2
3	1B	*	A02-4132-03	PLASTIC CABINET ASSY (16KEY)	K3,E
4	3A	*	A10-4148-01	CHASSIS	
6	3A		B01-0694-13	ESCUTCHEON	
7	1C		B09-0686-03	CAP ACCESSORY	
8	3B		B11-1869-04	ILLUMINATION GUIDE (TX/BUSY)	
9	1A	*	B11-1890-04	FILTER (LCD)	K2,K3,E
9	1A	*	B11-1890-04	FILTER (LCD)	E2
10	1A	*	B11-1891-02	ILLUMINATION GUIDE (LCD)	K2,K3,E
10	1A	*	B11-1891-02	ILLUMINATION GUIDE (LCD)	E2
11	1A		B38-0935-05	LCD	K2,K3,E
11	1A		B38-0935-05	LCD	E2
12	1A		B42-7417-04	STICKER	
13	2D	*	B62-2292-00	INSTRUCTION MANUAL (K TYPE)	K,K2,K3
14	2D	*	B62-2319-00	INSTRUCTION MANUAL (E TYPE)	E,E2,E3
16	1B,1D	*	D32-0454-04	STOPPER (16CH)	
18	3A		E04-0467-15	RF COAXIAL RECEPTACLE (SMA)	
19	2A	*	E23-1363-04	TERMINAL (ANT)	
20	1A	*	E29-1232-05	INTER CONNECTOR (LCD)	K2,K3,E
51	1A	*	J21-8631-03	MOUNTING HARDWARE (LCD)	K2,K3,E
51	1A	*	J21-8631-03	MOUNTING HARDWARE (LCD)	E2
52	1D		J29-0701-15	BELT CLIP ACCESSORY	
53	3A		J87-0027-05	FPC (LEAD FREE) (PTT)	
54	2A	*	J87-0040-05	FPC (LEAD FREE) (VOL/SELECTOR)	
56	1A	*	K29-9500-03	KNOB (PTT)	
57	1B	*	K29-9501-03	BUTTON KNOB (SIDE1/SIDE2/AUX)	
58	1B	*	K29-9485-03	KNOB (VOL)	
59	1B	*	K29-9486-03	KNOB (SELECTOR)	
A	3A		N09-2438-05	BINDING HEAD SCREW (ANT)	
B	3A	*	N09-6608-05	SPECIAL SCREW (CASE)	
C	3A	*	N14-0864-04	CIRCULAR NUT (VOL)	
D	3A	*	N14-0865-04	CIRCULAR NUT (SELECTOR)	
E	3A		N30-3006-43	PAN HEAD MACHINE SCREW (ESCU)	
F	1A,2A,3A		N83-2005-48	PAN HEAD TAPTITE SCREW (PCB)	
VR1	3A	*	R31-0685-05	VARIABLE RESISTOR (VOL)	
S101	3A	*	S60-0448-05	ROTARY SWITCH (SELECTOR)	
65	1A		T07-0787-05	SPEAKER	
-		*	X57-8040-11	SERVICE TX-RX UNIT	

# EXPLODED VIEW

