

# A82008102 Top Rear Panel KENWOOD Portable Radios Model TK-2000/3000

## Tapa Posterior de Arriba

**EPCOM syscom** ◇ 1630 Paisano Dr. ◇ El Paso. Tx 79901. Ph (915)533-5119

[www.epcom.net](http://www.epcom.net)

**SYSCOM** ◇ Ave 20 de Noviembre No. 805 ◇ Col. Centro ◇ Chihuahua, Chih. 31000

Tel 052 (614) 415 – 2525

[www.syscom.mx](http://www.syscom.mx)

# TK-2000

## PARTS LIST

\* New Parts. Δ indicates safety critical components.  
 Parts without **Parts No.** are not supplied.  
 Les articles non mentionnes dans le **Parts No.** ne sont pas fournis.  
 Teile ohne **Parts No.** werden nicht geliefert.

L : Scandinavia      K : USA      P : Canada  
 Y : PX (Far East, Hawaii)      T : England      E : Europe  
 C : China      X : Australia      M : Other Areas

TK-2000  
 TX-RX UNIT (X57-8093-00)

Ref. No.	Address	New parts	Parts No.	Description	Desti-nation	Ref. No.	Address	New parts	Parts No.	Description	
<b>TK-2000</b>						<b>TX-RX UNIT (X57-8093-00)</b>					
1	1A		A02-4135-13	PLASTIC CABINET ASSY		D400			B30-1782-05	LED(GREEN)	
2	3A		A10-4150-41	CHASSIS		D401			B30-1779-05	LED(RED)	
3	3B		A82-0081-02	REAR PANEL		C1			CK73GB1E154K	CHIP C 0.15UF K	
4	2B		B11-1892-03	ILLUMINATION GUIDE		C2			CK73HB1A184K	CHIP C 0.18UF K	
6	3B		E04-0486-05	RF COAXIAL RECEPTACLE(SMA)		C4		*	CS77MA1A6R8M	CHIP TNTL 6.8UF 10WV	
7	2A		E23-1364-04	TERMINAL		C5		*	CS77MA1ER68M	CHIP TNTL 0.68UF 25WV	
8	1B		E37-1539-05	PROCESSED LEAD WIRE(SP-BRN)		C6			CK73HB1A105K	CHIP C 1.0UF K	
9	1B		E37-1540-05	PROCESSED LEAD WIRE(SP+GRN)		C7			CC73HCH1H560G	CHIP C 56PF G	
10	2A		E72-0436-03	TERMINAL BLOCK		C8 ,9			CK73HB1A104K	CHIP C 0.10UF K	
11	2B		F10-3186-04	SHIELDING CASE(CF200)		C11			CK73HB1A105K	CHIP C 1.0UF K	
12	3B		G01-4571-04	COIL SPRING		C12			CC73HCH1H0R5B	CHIP C 0.5PF B	
13	2A		G11-4437-04	SHEET(Q102-SHASSIS)		C13			CS77MP1C010M	CHIP TNTL 1UF 16WV	
14	3A		G13-2364-14	CUSHION(BATT-GRAY)		C14 ,15			CK73HB1C103K	CHIP C 0.010UF K	
15	3A		G13-2366-04	CUSHION(TERMINAL)		C16			CK73HB1H102K	CHIP C 1000PF K	
16	2A		G53-1867-13	PACKING(CHASSIS)		C17			CC73HCH1H060B	CHIP C 6.0PF B	
18	1B		G53-1868-12	PACKING(TOP)		C18 ,19			CK73HB1H102K	CHIP C 1000PF K	
19	3B		G53-1869-13	PACKING(JACK)		C20			CS77MA1C100M	CHIP TNTL 10UF 16WV	
20	1A		G53-1871-14	PACKING(MIC)		C21 ,22			CC73GCH1H120G	CHIP C 12PF G	
22	1B		K29-9487-03	KNOB(VOL)		C23 ,24			CK73HB1H102K	CHIP C 1000PF K	
23	1B		K29-9488-03	KNOB(SELECTOR)		C25			CK73HB1C103K	CHIP C 0.010UF K	
24	1A		K29-9489-13	KNOB(PTT)		C26			CK73HB1H102K	CHIP C 1000PF K	
25	1A		K29-9490-13	BUTTON KNOB(SIDE)		C27			CC73HCH1H220J	CHIP C 22PF J	
26	3A		K29-9491-03	LEVER KNOB(BATTERY)		C28			CK73HB1H102K	CHIP C 1000PF K	
A	2B		N09-2438-05	BINDING HEAD SCREW(ANT)		C29			CC73GCH1H0R5B	CHIP C 0.5PF B	
B	3A		N30-2606-48	PAN HEAD MACHINE SCREW(CABINET)		C30			CK73HB1H102K	CHIP C 1000PF K	
C	1A,2A		N83-2005-48	PAN HEAD TAPTITE SCREW(X57)		C31			CK73HB1C103K	CHIP C 0.010UF K	
28	1B		T07-0787-05	SPEAKER		C32			CK73HB1H102K	CHIP C 1000PF K	
						C33			CC73HCH1H470J	CHIP C 47PF J	
						C34			CK73HB1H102K	CHIP C 1000PF K	
						C35			CC73HCH1H150J	CHIP C 15PF J	
						C36			CC73HCH1H120G	CHIP C 12PF G	
						C37			CC73HCH1H150J	CHIP C 15PF J	



